

Fahrzeugausschläge in Gleisbogen

r	w _a	w _i
m	mm	mm
20000	1	1
15000	2	2
10000	3	2
7500	3	3
7000	4	3
6500	4	3
6000	4	4
5500	4	4
5000	5	4
4500	5	5
4000	6	5
3500	7	6
3000	8	7
2500	9	8
2000	11	10
1900	12	10
1800	13	11
1700	13	11
1600	14	12
1500	15	13
1400	16	14
1300	17	15
1200	19	16
1100	20	17
1000	22	19
900	25	21
800	28	24
700	32	27
600	37	31
550	40	34

r	w _a	w _i
m	mm	mm
500	44	38
450	49	42
400	55	47
350	63	53
300	74	62
275	80	68
250	88	75
225	98	83
200	110	93
190	116	98
180	122	103
175	126	106
170	130	110
160	138	116
150	147	124
140	157	133
130	170	143
125	176	149
120	184	155
110	200	169
100	221	186
90	245	207
80	276	233
70	316	266
60	369	310
50	445	373
40	560	467

r = Bogenhalbmesser

w_a = Fahrzeugaußenausschlagw_i = Fahrzeuginnenausschlag